

JABSCO Spare Parts List



Repair Kits Available		
Kit	Part No	Description
A	29045-0000	SERVICE KIT (UP TO 1997)
B	29040-2000	PUMP ASSEMBLY
C	29094-2000	VALVE COVER ASSEMBLY
D	29051-2000	PUMP CYLINDER ASSEMBLY
E	29047-0000	BASE TO BOWL MOUNTING KIT

Key	Description	Qty Per Toilet	Part No	Qty per Repair Kit				
				A	B	C	D	E
1	BOWL COMPACT TOILET	1	29096-0000					
	BOWL REGULAR TOILET	1	29126-0000					
2	SEAT, LID & HINGE SET	1						
	COMPACT TOILET		29097-1000					
	REGULAR TOILET	1	29127-1000					
3	HINGE SET (1 PAIR)	1	29098-1000					
4	HOSE COMPACT TOILET	1	29035-1000					
	HOSE REGULAR TOILET	1	29035-1001					
5	INTAKE SEAL +	1						
6	INTAKE ELBOW	1	29048-1000					
7	BASE, PLUG + O-RING ASSY	1	29041-1000					
8	PLUG + O-RING ASSY (UP TO 2002 - SCREW)	1	29028-0000					
	(FROM 2003 - BAYONET)	1	29028-2000					
9	O-RING (PLUG)	1	-					
10	O-RING (BOWL)	1	-				1	
11	BOLT (S/S)	4	-				4	
12	NUT (S/S)	4	-				4	
13	WASHER (S/S)	4	-				4	
14	WASHER (NYLON)	4	-				4	
15	CAP	4	-	2			4	
16	BASE VALVE GASKET	1	29043-0000	1	1		1	

Key	Description	Qty Per Toilet	Part No	Qty per Repair Kit				
				A	B	C	D	E
17	HANDLE	1	29026-2000		1			
18	SEAL HOUSING ASSY (UP TO 1997)	1	29044-0000	1	1	1		
	(FROM 1998 ONWARDS)	1	29044-2000	1	1	1		
19	TOP VALVE SEAT	1	-	1	1	1	1	
20	CAM	1	-		1	1		
21	TOP VALVE GASKET	1	29042-0000	1	1			
22	O-RING (FLUSH LEVER)	1	-		1	1	1	
23	FLUSH CONTROL LEVER	1	-			1	1	
24	SCREW (FLUSH LEVER)	1	-		1	1	1	
25	BUFFER	1	-		1	1		
26	SCREW (VALVE COVER)	6	-		1	6	6	
27	VALVE COVER	1	-			1	1	
28	PUMP CYLINDER	1	-		1	1	1	
29	PISTON, ROD & O-RING ASSY	1	29046-0000			1		
30	O-RING (PISTON)	1	-			1	1	
31	SCREW (PUMP CYLINDER)	6	-			1	2	2
32	DISCHARGE FLANGE	1	29091-1000			1	1	1
33	JOKER VALVE	1	29092-1000		1	1	1	1
34	DISCHARGE ELBOW	1	29029-1000			1	1	
35	VALVE SPRING (ONLY FROM 1998)	1	-			1	1	